
Manually Clean Printer.

Steps


Step 1: Open printer top cover and remove toner to reveal inside of printer.



Step 2: Yellow arrows point to plastic retaining clips. Using a screwdriver or other suitable tool - ease retaining clips.



Step 3: Clean roller using a clean rag and methylated spirit (or other suitable cleaner) and refit. **Step 4:** Red arrows point to a plastic retaining clip. Push clip together with fingers or other suitable tool.



Step 5: Clean roller using a soft brush and replace (please note the orientation of the clip).